

<u>.</u> 4.	Setup.exe 를실행합니다.	SMAP-CD
5.	Ok 를 클릭합니다.	 SMAP-CD Data Programs Setup.exe Setup.Lst Smap_lnstall_Guide.pdf Smap_Install_Guide.pdf
6.	Next 를 클릭합니다.	OK Exit Setup
	다음 화면이 나올 때까지	Selecting SMAP Programs
	몇분 소요될 수 있습니다.	Select Setup No Image: Setup 1 All Programs (Recommend) Image: Setup 2 3D Set : S2, S3, 2D, 3D, Tuna, Tuna Plus Image: Setup 3 2D Set : S2, 2D, Tuna, Tuna Plus Image: Setup 4 Thermal Set : T2, T3 Image: Setup 6 Tuna Image: Setup 11 Smap S2 Image: Setup 13 Smap 2D Image: Setup 14 Smap 3D Image: Setup 15 Smap T2 Image: Setup 16 Smap T3

7.	Continue 를 클릭합니다.	🛃 SMAP - Choose Program Group X
		Setup will add items to the group shown in the Program Group box. You can enter a new group name or select one from the Existing Groups list. Program Group: SMAP Existing Groups: Accessibility Accessories Administrative Tools Maintenance SMAP Startup System Tools Windows PowerShell Qontinue Cancel
8.	OK 를 클릭합니다.	SMAP Setup X
		OK]
9.	OK 를 클릭합니다.	Successful Smap Installation X
		Please delete: C:\SmapSetupAdd.dat and C:\SmapSetupLog.dat
		()

4 Installing SMAP Programs

Note:

.

Following two log files will be generated once finished: C:\SmapSetupAdd.dat C:\SmapSetupLog.dat

If Smap Installation is successful, delete these two files.

If Smap Installation is not successful, follow the instruction in SmapSetupAdd.dat.

If you still have problems with Smap Installation, send these two files to info@ComtecResearch.co.kr

For TUNA and TUNA Plus, Minimum System Requirement is Windows 32 bit.